



Bouwvelven 1  
B - 2280 Grobbendonk  
Belgium

Tel. +32 14 230001  
Fax +32 14 230880

## 11. AWLGRIP SYSTEM FOR BARE / NEW WOOD

### SURFACE ABOVE THE WATERLINE

11.1. Thoroughly sand the wood with 80-120 grit sandpaper. Blow off sanding dust and residue with clean, dry compressed air. Clean the surface using **Surface Cleaner T340** and in case of high humidity / dew point **Awl-Prep T0008**. Use the two cloth method. Make sure no oily type of contamination is present.

11.2. Seal the wood with **Awlgrip 545 Anti-Corrosive Epoxy Primer White**. Allow the seal to cure 8-12 hours at 20°C. before recoating. If more than 24 hours elapse, the seal coat must lightly be sanded with grit 180-220 grit paper before proceeding. Sealcoat of 545 Primer can be applied by brush, roller or spray method.

Base	: White D8001
Converter	: D3001
Reducer	: Spray application : 40 % with T0006 Brush application : 40% with T0031
Induction time	: 15 minutes
Recommended film thickness	: 175 - 250 micron wet = 50 - 75 micron dry (calculated for mixed base and converter reduced 25 %)

11.3. Apply **Awlgrip 545 Anti-Corrosive Epoxy Primer Gray** or **White**. Allow 2 hours minimum between coats at 20°C. Allow to cure 12 - 14 hours.

Base	: Gray D1001 White D8001
Converter	: D3001
Reducer	: up to 25 % T0006 (min. 10 % T0006)
Induction time	: 15 minutes
Recommended film thickness	: 175 - 250 micron wet = 50 - 75 micron dry (calculated for mixed base and converter reduced 25 %)

Sand with 80 - 120 grit paper. Do not break through to bare wood! Should you break through, reprime these areas immediately with Awlgrip 545 Gray Primer.



Bouwvelven 1  
B - 2280 Grobbendonk  
Belgium

Tel. +32 14 230001  
Fax +32 14 230880

11.4. Apply by trowel, as necessary, **AwlFair Trowelable Fairing Compound Light Weight:**

Base	: D8020 White
Converter	: D7007 Red
Mixing ratio	: <u>1/1 by volume</u>
Color	: pink
Induction time	: no induction period needed
Potlife	: 30 - 45 minutes

Mix by volume 1 part D8020 with 1 part D7007 converter. Mix well until a uniform pink color is obtained. Mixing must be thorough to insure a good cure. Awlfair can be sanded after a drying period of 24 hours at 20°C. Blocksand the Fairing Compound with grit 40, 60 or 80 in between the coats and before each next step. Remove all sanding residue with clean dry compressed air before each next step.

Before proceeding to next coat, make sure no surface contamination is present.

***Do not add thinners or reducers to the Awlfair Fairing Compound !***

11.5. Apply one layer of **Ultra-Build Epoxy Primer** in 2 or 3 coats with a drying time in between the coats of minimum 2 hours and maximum 12 hours at a temperature of 20°C.

Base White	: D8008
Converter	: D3018
Mixing ratio	: 1:1 in volume
Reducer	: 5-10% with T0073
Induction time	: 15 minutes after mixing
Recommended film thickness	: 625 - 750 micron wet = 375 - 500 micron dry

After drying sand the surface with grit 120. Remove all sanding residue with clean dry compressed air thoroughly and use **Surface Cleaner T340** and in case of high humidity / dew point **Awl-Prep T0008** to clean the surface. Use the two cloth method. Make sure no oily type of contamination is present.

11.6. Apply one coat of **Awlgrip 545 Anti-Corrosive Epoxy Primer** Gray or White.

Base	: White D8001 Gray D1001
Converter	: D3001
Reducer	: up to 25% T0006 (min. 10 % T0006)
Induction time	: 15 minutes
Recommended film thickness	: 175 - 250 micron wet = 50 - 75 micron dry (calculated for mixed base and converter reduced 25%)

If necessary in order to cover sanding scratches, more coats can be applied. Allow a drying time of minimum 8 hours and maximum 24 hours at 20°C. in between the coats.



Bouwelven 1  
B - 2280 Grobbendonk  
Belgium

Tel. +32 14 230001  
Fax +32 14 230880

Sand the 545 Primer with 220-400 grit paper. This is necessary to provide a smooth surface for topcoat application.

Remove all sanding residue with clean dry compressed air and use **Surface Cleaner T340** and in case of high humidity / dew point **Awl-Prep T0008** to clean the surface. Use the two cloth method. Use **Awlgrip 73009 Premium Tack-Rags** prior to topcoating. Check the cleaned surface.

11.7. To obtain gloss, depth, and complete coverage apply **Awlgrip Topcoat** as follows:

Using recommended spray equipment, apply a light, smooth, slightly wet tack coat to the surface. Allow tack coat to 'flash off' 30 to 45 minutes. Then apply a full coat to achieve color coverage (i.e. hide) and film thickness requirements. If preferred, three coats may be used. Allow the second coat to 'flash off' 30 to 45 minutes until only slightly tacky before applying third coat.

***Topcoating cannot be done in one coat!***

Base	: see color card
Converter	: G3010
Mixing ratio	: 1/1 by volume
Reducer	: ± 25% T0001 below 21°C. ± 25% T0003 above 21°C.
Induction time	: 15 minutes
Recommended film thickness	: 150 - 200 micron wet = 50 - 75 micron dry

For application of **Awlgrip Topcoat** by brush :

Base	: see color card
Converter	: H3002
Mixing ratio	: 2/1 by volume
Reducer	: 10-20% T0031
Induction time	: 15 minutes
Recommended filmthickness:	wet 100 - 150 micron = 50 - 75 micron dry

***Do not paint below a temperature of 18 °C !***

- **Note** : Some colors may require more than 75 micron of dry film to achieve full hide or opacity, extra coats may be needed to achieve a dry film thickness greater than 75 micron.